



# Quick Set Latex Concrete Repair™

## Polymer modified concrete repair mortar

### Repair Thickness

Featheredge to 1½"

### Set Time

20 minutes

### Application Technique

Trowel

### Where to Use

- Smooth and fill depressions
- On concrete, wood, plywood, ceramic
- Naval vessels
- Underlayment for tile & carpet
- Over prepared waterproof adhesives
- Driveways, sidewalks
- Interior or exterior

### Features

- Polymer modified
- Portland cement based
- Self-curing, self-bonding
- Waterproof underlayment
- Short setting time—Under an hour
- One component—Just add water

### Packaging and Yield

50 lb pail	50 sq ft at ⅛"
20 lb pail	20 sq ft at ⅛"

## Product Description

**Quick Set Latex Concrete Repair** is a 1 component, polymer modified, high performance repair. **Quick Set Latex Concrete Repair** is simply mixed with water and applied to concrete, wood, plywood or ceramic from featheredge to 1.5" thick in one application. Apply horizontal, vertical or overhead. Apply with trowel, brush or broom. Product sets in 20 to 45 minutes and is ready for light traffic in 3 to 4 hours at 70°F.

**Quick Set Latex Concrete Repair** is a special blend of cement, aggregate and exclusive modifiers. Designed for general purpose and high performance concrete repair.

### For Best Results

Apply to a clean, dry sound substrate above 40° F. Rub or scratch part of the mixed material onto surface just prior to application. Do not allow rub or scratch coat to dry before application. Check moisture content (mat test) prior to applying any waterproof topping. Do not retemper already mixed material.

### Surface Preparation

Surface preparation is critical to achieve long lasting results. Existing concrete surface shall be clean, sound, and free of oil, grease, laitance, curing compounds, or any other foreign substance. Preparing surface by mechanical means such as grinding or shot blasting is recommended. Areas treated with product must be free of dust and any foreign matter prior to topping application. On highly porous substrates, contact the manufacturer for recommended application procedures.

### Mixing Guidelines

Approximately 4 to 5 quarts of water are required to mix 50 lb of product for troweling. Rub or scratch mixed material onto surface just prior to application. For brush or broom applications, 1.5 gallons of water is recommended. Force action mixing for 2 to 3 minutes is recommended.

### Application

Rub or scratch part of the mixed material onto surface just prior to application. Trowel, brush or broom apply to clean surface. For uniform finish, apply with brush or broom in the same direction.

### Curing

Avoid applications in high winds, excessive heat or blowing air directly on freshly placed product. Product sets in 20 to 45 minutes. Allow 3 to 4 hours for light traffic on horizontal repairs. Contact JE Tomes if you have any questions or concerns with your application.